

TREATMENT INSTRUCTIONS

2- Stroke Motorcycle Engine Kits

NOTE: Read through the entire instruction sheet before installing any Microlon Products.

To Install the Microlon Products-

- 1) Bring the engine to operating temperature.**
- 2) Shut the engine off to apply the product.**
- 3) Shake the Microlon containers for at least one minute. Add the measured amount of engine treatment to the mixed fuel and add to the engine's fuel tank.**
- 4) Immediately operate the engine for an hour.**

NOTE: Microlon is compatible with all 2 Stroke oils including synthetics. Only add Microlon to a mixed fuel container or to the fuel tank. Do not add to oil injection tanks.

NOTE: If your motorcycle has been unused for some time, it is recommended that the engine is run to check for seal leaks. Long- term storage may cause seals to become brittle and dry and can lead to cracks and leaks. Any leaks found should be repaired prior to Microlon treatment.

**Microlon, Inc 217 Trademark Dr. Buda, Texas 78610 USA
Order Desk: (512) 295-9895 Toll Free Order Desk: (800) 962-4152
Tech Support: (512) 247-8172 FAX: (512) 295-9896**