

TREATMENT INSTRUCTIONS

Transmission, Differential, Power-Steering & Wheel- Bearing Grease Treatment

NOTE: Read through the entire instruction sheet before installing any Microlon Products.

AUTOMATIC TRANSMISSION- 1) Shake the Automatic Transmission Treatment well for one full minute. 2) Remove an amount of transmission fluid equal to the amount of Microlon to be added. 3) Add the Microlon Automatic Transmission Treatment.

MANUAL TRANSMISSION- 1) Shake the Compound 90 until it is an even color. 2) It may be necessary to remove some of the fluid from the Manual Transmission reservoir. 3) Add the recommended amount of Microlon Compound 90.

DIFFERENTIAL- 1) Shake the Compound 90 until it is an even color. 2) Remove an amount of fluid equal to the amount of Compound 90 to be added. 3) Add the Compound 90 to the differential gear box.

POWER STEERING UNIT- 1) Shake the 2 ounce Power Steering Treatment well. 2) To avoid overflow, it may be necessary to remove some of the existing fluid. 3) Add the entire contents of the 2 ounce can to the power steering reservoir.

WHEEL BEARINGS- Pack the wheel bearings with Microlon High Temperature Bearing Grease.

NOTE: Once the Microlon products have been added to the critical part of the vehicle, the car/ truck must be operated for an hour or 100 miles to get the full effect of the treatment.